

Quad Stack Double Oscillator Critical Spare Parts List

Item No.	Part No.	Description	Recommended On-Hand Quantity
1	001132	Brush Roll Bearing	4
2	001016	ER-16C Bearing	6
3	001068	3/4" Bearing	4
4	001131	Water Roll Bearing	4
5	051313	Pneumatic Valve	1
6	060077	Module To Module Drive Belt	1
7	060078	Main Drive Belt	1
8	090007	Blanket	8
9	1514380	Ink Fountain Seal	2
10	11000670	2 3/8" Rubber Dampener Roll	1
11	11000650	2 1/2" Rubber Ink Roll	1
12	002083	Oscillator Gear Box Slider	2
13	11006150	Roller Hanger Bracket (Lower)	1
14	11006250	Roller Hanger Bracket (Upper)	1
15	11020050	Roller Hanger Bracket Stud (Lower)	1
16	11020100	Roller Hanger Bracket Stud (Lower)	1
17	514370	3" Rubber Ink Roll	1
18	514640	2 7/8" Rubber Ink Roll	2
19	060056	Timing Belt, L-Section	1
20	001006	Drive Shaft Bearing	2
21	001023	Idler Bearing	2
22	001074	Oscillator Gearbox Bearing	4
23	040055	Brush Motor Page 1	1
24	040057	Brush Motor Page 2	1
25	040919	Water Fountain Motor	1
26	051340	Form roll Air Cylinder	1
27	051349	Impression Air Cylinder	1
28	067079	Oscillator Worm Gear	1
29	11001260	Ink Fountain Motor Page 1/ Page 2	2
30	11003400	Oscillator Worm Gear Spacer	2
31	11003501	Oscillator Gearbox Bearing Plate	1
32	11003601	Oscillator Side Plate	1
33	11003650	Oscillator Gearbox Bearing Plate	1
34	11003751	Oscillator Slide Plate Page 1	1
35	11004003	Oscillator Gear Assembly	1
36	11004050	Oscillator Horizontal Slider	1
37	11004101	Oscillator Slide Plate Page 2	1
38	040117	Gear Motor, DC	1
40	051313	Pneumatic Valve Assembly	2